

ABOUT MID-SEMESTER EXAM


- May 14th, 2022.
- Totally offline.
- Will have examination in two batches.
 - Batch 1: 10 AM to 12 noon
 - Batch 2: 1 PM to 3 PM
- Batch 1 has to report at 9.30 AM.
- Batch 2 has to report at 12.30 PM.
- Do not come late.
- Bring your instruments.
- No mobile phones inside examination halls.

Auxiliary Views


Question?

How should we trim a flat sheet for making the part on

the left?




Approach




Principal Orthographic Views: Review

- The object is placed inside a glass box.
- The sides of the box represent the 6 principal planes.
- Planes connected by hinge joints.



Glass Box Method

- The image of the object is projected on the sides of the box.
- But there could be surfaces which will appear distorted.
 - Some planes may not be seen in respective true shapes.




Important Points

Foreshortening of lines that are inclined to the H/F/P planes.

 Normal or "true shapes" cannot be drawn if its planes are inclined to H/F/P planes.


Principal Orthographic Views



Auxiliary View


 An orthographic view that is not on one of the principal plane.

 Projector lines intersect the auxiliary plane normally.




Line of Sight


The Auxiliary Box



Unfolding the Box



Completed Auxiliary View



Viewing Direction for Auxiliary Views

 If the viewing direction is perpendicular to the target surface, one gets the "Normal View".

Some views

- Normal view of a line: True length
- Point view of a line
- Edge view of a plane
- Normal view of a plane: True surface

Illustration: Developing








Illustration: Developing


Auxiliary Views



Auxiliary View: Orthographic View that is not on Principal Planes




Auxiliary Views: How Many Views for This Object?





Auxiliary Views: How Many Views for This Object?

- Four orthogonal views: Include two partials.
- Two auxiliary views.




Examples: Objects with Inclined Faces: Inclined to How Many Planes?







Auxiliary Planes: *Foreshortening of Lines*




Positioning the Central Plane




- 1. Draw the partial front and top views and locate the view direction.
- 2. Locate the reference plane a in (c)
- 3. Transfer distance from reference plane to normal view. (d).
- 4. Complete normal view.
- 5. Complete the top view.



Note: Sometimes Foreshortened Views are Not Shown Completely (Partial Views)



Partial Views










Illustration: Draw the normal surface first then complete the drawing via auxiliary views.





Side Auxiliary View





Front Auxiliary View

