
## Activation Energy of a Reaction

#### The Collision Model

- In a chemical reaction, bonds are broken, and new bonds are formed
- Reactant molecules react upon collision between each other
- The orientation and energy during the collision are decisive in the bond breaking and formation




# **Activation Energy**

- Every chemical reaction is characterized by an energy that the reactants need to overcome in order to form the products, known as activation energy,  $E_a$
- A reaction cannot occur unless the reactant molecules possess sufficient energy to overcome the activation energy barrier




### **Reaction Coordinate**

The reaction coordinate for the rearrangement of Methyl Isonitrile molecule is shown below.




- The highest point on the diagram is known as the transition state and the structure is called as the activated complex
- The energy gap between the reactants and the activated complex is the activation energy

#### Maxwell-Boltzmann Distributions



- The average kinetic energy of the reactants in gaseous/liquid state is related to the temperature
- The distribution of kinetic energies of reactants are given by Maxwell–Boltzmann Distributions
- As the temperature increases, the broadening of the distribution increases. That is at higher temperature, the population of molecules with higher energy is high.

### Maxwell-Boltzmann Distributions



At high temperature the fraction of molecules that can overcome the activation energy barrier is high. That is the formation of products increases.

## **Arrhenius Equation**

Svante Arrhenius developed a mathematical relationship between rate constant of a reaction, k, and  $E_a$ 


$$k = A e^{-\frac{E_a}{RT}}$$

where A is the frequency factor, a number that represents the likelihood that collisions would occur with the proper orientation for reaction.

## **Arrhenius Equation**

$$k = A e^{-\frac{E_a}{RT}}$$

Taking the natural logarithm of both sides, the equation becomes the following and has the form of the equation for line.



When k is determined experimentally at several temperatures,  $E_a$  can be calculated from the slope of a plot of  $\ln(k)$  vs 1/T.

# To Determine the Activation Energy of a Reaction

In this experiment we will study the reaction between potassium permanganate and dilute oxalic acid at different temperatures. The permanganate ion MnO<sub>4</sub>- reduces to MnO<sub>2</sub> and is detectable by the change in color from bright purple/pink to yellow/brown. We will find the rate constant for this reaction at five different temperatures and determine the activation energy for the reaction.


#### **Experimental Protocol**

- 1. Using burettes, place 20 mL oxalic acid (0.5 M) in a conical flask and 10 mL KMnO4 (approximately 0.02 M) in a test tube.
- 2. Immerse both conical flask and test tube in a water bath to equilibrate for at least 5 minutes.
- 3. Mix the reactants in a conical flask and immediately start a stopwatch.
- 4. Swirl the reaction mixture regularly without removing it from the water bath.
- 5. Record the time it takes for the mixture to turn yellow/brown (indication of reduction of  $MnO_4$  to  $MnO_2$ ).
- 6. Repeat the procedure with another mixture (exam same quantities) at the same temperature.
- 7. Repeat steps 1 to 6 for three different temperatures.
- 8. For the reading at 0 degree Celsius, time taken is 2160 seconds. Use this information as the fifth temperature reading in your experiment.
- 9. Determine the activation energy by plotting ln(k) Vs 1/T. (Temperature need to be converted to Kelvin).

## **Observations**


[KMnO4] = 0.02M[Oxalic Acid] = 0.5 M

S.	Temp	Temp	1/T (K <sup>-1</sup> )	Time for	Time for	Average	Rate=	$k = \text{Rate/[KMnO}_4]$	ln (k)
No.	(°C)	(K)		trial 1 (s)	trial 2 (s)	Time (s)	[KMnO <sub>4</sub> ]/time	[Oxalic]	
1	0	273	36.6 x 10 <sup>-4</sup>	2155	2165	2160	$0.93 \times 10^{-5}$	$0.93 \times 10^{-3}$	-6.980
2	28	301	33 x 10 <sup>-4</sup>	183	179	181	1.105 x 10 <sup>-4</sup>	1.105 x 10 <sup>-2</sup>	-4.505
3	40	313	31.95 x 10 <sup>-4</sup>	61	63	61	3.28 x 10 <sup>-4</sup>	3.28 x 10 <sup>-2</sup>	-3.417
4	50	323	31 x 10 <sup>-4</sup>	27	31	29	6.9 x 10 <sup>-4</sup>	6.9 x 10 <sup>-2</sup>	-2.67
5	60	333	30 x 10 <sup>-4</sup>	11	11.53	11.26	17.76 x 10 <sup>-4</sup>	17.76 x 10 <sup>-2</sup>	-1.73



## **Observations**

Image of a graph ln k vs 1/T



#### **Observations and Calculations**

$$\ln(k) = -\frac{E_a}{RT} + \ln(A)$$

From graph;

Slope = 
$$-E_a / R = 0.7955$$

$$E_a = 66134 \text{ J/mol}$$

### **Results**

The rate of reduction of MnO<sub>4</sub><sup>-</sup> to MnO<sub>2</sub> was monitored at different temperatures to determine the Activation Energy for the reaction.

Activation energy = 66.134 KJ/mol